



POWERHOLD

MULTIPURPOSE FLOORING ADHESIVE

Multi Adhesivo de Solado de Propósito

DESCRIPTION:

POWERHOLD 3000 MULTIPURPOSE FLOORING ADHESIVE is a solvent free, non-flammable, latex based adhesive used for the interior installation of a wide variety of flooring materials. 3000 has excellent open time, wet tack and high ultimate strength. DO NOT USE OUTDOORS.

USE TO INSTALL:

Carpet: Most carpet backings such as jute, latex unitary, woven polypropylene (ActionBac®), needle punched, Duragon backed, indoor/outdoor, rubber back and most backings designed for the installation of direct glue down. Resilient: all felt-backed residential sheet goods. Do not use to install vinyl backed carpets or sheet goods.

FOR USE OVER:

Concrete: above, on or below grade in the absence of excessive moisture and alkali. APA registered plywood underlayment, hardboard, association grade particle-board. Not recommended over existing vinyl flooring.

PRIOR TO INSTALLATION:

Floor must be clean, level and dry. Remove all foreign substances such as wax, grease, dirt and any substance or chemical that would interfere with a good bond. Fill all holes and cracks with a cement based patching compound. Sand high spots, install felt or hardboard underlayment over tongue and groove flooring to eliminate the possibility of telegraphing. For best results, the room, floor covering and adhesive should be 65°F (18°C) or above for 24 hours before, during and after the installation.

INSTALLATION INSTRUCTIONS:

1. Apply adhesive to substrate with the recommended notch trowel (trowel size will depend on the type of backing and smoothness of the substrate). Minimum trowel size for carpet is 3/32"x3/32"x3/32" (2.4mm x 2.4mm x 2.4mm) V-notch. Lay most floor coverings into wet adhesive. Open time will vary from 15 min-

utes to one hour, depending on the dryness of the floor, thickness of adhesive application, temperature and humidity. When installing on a non-porous surface, allow adhesive to get slightly "tacky" before laying in carpet.

2. Lay in flooring, lifting occasionally to be sure of making 100% contact with backing.

3. Roll carpet immediately after installation with a 30-50 lb. (13.6-22.7 kg) roller. Roll sheet goods with a 75-100 lb. (34-45.4 kg) linoleum roller. Work from the center towards the edges to expel trapped air.


4. Seal all seams according to the flooring manufacturer's recommendations. For carpet, use POWERHOLD 20/25/40 Carpet Seam Adhesive.

5. Clean up: Use soap and water if adhesive is still wet. If dried, use POWERHOLD Cleaning Solvent.

CAUTION:

DO NOT take internally. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN.





3000

TECHNICAL SPECIFICATIONS

For Product No.: 3000
Powerhold Trade Name: Multi Purpose Flooring Adhesive
VOC's: Negligible
Base: Synthetic rubber, resin blend
Color: Beige
Consistency: Smooth medium viscosity paste
Open Time: 15-60 minutes under normal conditions
Flammability: Non flammable
Freeze Thaw Stability: Stable
Clean Up -
When Adesive is wet: Warm Soapy Water
When Adesive is dry: Powerhold 50 Cleaning Solvent

PACKAGING

4 Gallon (15.14L) Black Plastic Pails

SHELF LIFE

1 - Year when stored in original, unopened container

COVERAGES (APPROXIMATE)



Up to 250 sq. ft./gal
Up to 6.1 sq. meters/liter
1.6mm x 1.6mm x 1.6mm
• Sheet goods



Up to 72 sq. ft./gal.
Up to 1.8 sq. meters/liter
3.2 mm x 3.2 mm x 1.6 mm
• Rough backed and ribbed carpet



Up to 160 sq. ft./gal.
Up to 4.0 sq. meters/liter
2.4mm x 2.4mm x 2.4mm
• Smooth backed carpets



Up to 110 sq. ft./gal.
Up to 2.7 sq. meters/liter
3.2 mm x 3.2 mm x 1.6 mm
• ActionBac® / Jute, Urethane (attached cushion) & Hot Melt Backed Carpets
[Most Backed Carpet]