



ANTI-FRACTURE MEMBRANE

FOR CERAMIC TILE, MARBLE, STONE, CONCRETE, PLYWOOD AND MORE

PROTECT YOUR TILE FLOOR IN 4 EASY STEPS

- 1 Clean Subfloor
- 2 Prime Subfloor
- 3 Peel & Stick Membrane
- 4 Install Tile

A 40 mil (1 mm) thick reinforced peel and stick sheet membrane specifically designed for use under ceramic tile, porcelain and natural stone as a stress relieving material in conjunction with thinset methods.



- Aggressive rubberized adhesive
- Anti fracture resistant up to 3/8"
- Fabric top coating allows for immediate installation of the new tile or stone
- No curing time needed



WWW.POWERHOLD.COM