

Installing Powerhold **ALUMINUM LVT TRIMS**

1. It can be anchored into concrete via drilled anchor holes and fasteners.



[GET TECH DATA HERE](#)

2. It can be secured, chemically, with a product similar to our PH 949 Invisinail.



[GET IT HERE](#)

4. It can be fastened into wood, via the appropriate nails or screws.



[GET IT HERE](#)

5. A high-strength glue stick, like our Pamtite, may be used.