



Cure Time

24 Hrs



Rolling Loads

24 Hrs



Foot Traffic

Immediate
Occupancy

pH

7-12



RH

Up to 99%



Dry Time

30+ Mins



Working Time

12 Hrs

Suitable Substrates

Use on concrete substrates with up to 99% RH for flooring installed on or above grade (per ASTM F2170), and pH up to 12. Below grade installations are limited to 95% RH and 10 pH. For PVC modular carpet tile, RH is limited to 95% and pH up to 10. For Vinyl Sheet and Fiberglass Reinforced Sheet Flooring, RH is limited to 90% and pH up to 10. Please use approved primer for overly porous substrates (i.e. gypsum) as per ASTM F2419.

Cleanup

While wet, always apply soapy water to a clean cloth and wipe away adhesive. When material is dry, use denatured alcohol or appropriate adhesive remover. Do not pour directly onto flooring.

Storage

Store unopened between 50-90°F. Shelf life is 2 years unopened. Do not allow product to freeze.

Disclaimer

Users should determine suitability of this information or product for their own purpose or application. Manufacturer is not responsible for the misuse of this product. This adhesive is not a moisture barrier and should not be installed/treated as such. This adhesive is not a substrate moisture sealer and does not form a protective barrier and is only warranted to maintain an adhesive bond when used over substrates specified in this document. ASTM 2659 impedance readings that exceed 4% may void the warranty.

Not a dangerous substance or mixture according to OSHA 29 CFR 1910. 1200.

First Aid Measures

Eye contact: Rinse immediately with plenty of water also under the eyelids, for at least 15 minutes. Do not rub affected areas. If eye irritation persists: Get medical advice/attention.

Skin contact: Wash off immediately with plenty of water for at least 15 minutes. In the case of skin irritation or allergic reactions see a physician.

Inhalation: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

Ingestion: Do not induce vomiting without medical advice. Never give anything by mouth to an unconscious person. If symptoms persist, call a physician. Self-protection of the first aider: Use personal protective equipment as required.

Disposal

Dispose of in accordance with local, regional, national, and international regulations as specified. Read SDS for detailed product information. SDS may be obtained by visiting the website.

24-HOUR EMERGENCY CONTACT Chemtrek
(Transport/Environmental)

1-800-424-9300 or 1-703-527-3887 (Outside U.S.)
Rocky Mountain Poison Center: 1-866-767-5089

PREMIUM UNIVERSAL ADHESIVE

APPLICATIONS & COVERAGE

LVP, LVT, VCT, SVT, Modular Carpet Tile

Up to 260 sqft/gallon

1/6" x 1/32" x 1/32" U

1/16" x 1/32" x 1/32" U

Homogeneous and Heterogenous Sheet
Goods (porous substrate), double stick
pad to substrate

Up to 180 sqft/gallon

1/16" x 1/16" x 1/16" Square

1/16" x 1/16" x 1/16" SQ

Resilient Sheet (fiberglass) and Carpet Tile

Up to 360 sqft/gallon

3/8" Short Nap Paint Roller



FOR PROFESSIONAL USE ONLY. NOT LABELED FOR CONSUMER USE.
KEEP OUT OF REACH OF CHILDREN.

1 US Gallon (3.79 L)

Instructions & Additional Info

For detailed installation guidelines, approved substrates, proper substrate preparation, technical data sheet, and safety data sheet, please see website.

APPROVED PRODUCTS:

Luxury Vinyl Tile (LVT), Luxury Vinyl Plank (LVP), Modular Carpet Tile (Approved backings: non-PVC, Polyolefin, Felt, PVC), Vinyl Composite Tile (VCT), Vinyl sheet and Fiberglass Reinforced Sheet Flooring, Double Glue Down Carpet Installations (pad to substrate), Solid Vinyl Tile and Plank.

INSTALLATIONS:

DISCLAIMER: FOLLOW THESE INSTRUCTIONS COMPLETELY OR DO NOT USE THIS PRODUCT.

1. *** If unfamiliar with a product, always perform a bond test. Spread a small area of adhesive and install the desired floor covering into the adhesive to ensure the desired bond is achieved. ***

2. After surface preparation, spread adhesive using recommended trowel or roller as needed for desired flooring type.

Dry - Set PSA (porous and non-porous substrate)

- Spread adhesive using required tools.
- After spreading the adhesive using the recommended trowel, wait 30-60 minutes for adhesive to flash off. When ready the adhesive will turn translucent and will not transfer to fingertips when touched.
- Working time: 12 hours depending on ambient conditions and porosity of the substrate.
- Only apply as much adhesive as can be installed within a 12-hour period. Protect the adhesive from dust and debris, which will inhibit proper adhesive bond and decrease tack.

SEMI-WET SET (porous substrates only)

- After spreading the adhesive using the recommended trowel, wait 15-25 minutes for adhesive to flash off installing sheet vinyl into the semi-wet adhesive with transfer to floor covering backing.
- Working time: 20-30 minutes depending on ambient conditions and porosity of the substrate.
- Be sure to install flooring during the working time of the adhesive.
- 3. After installation, roll flooring with 75-100lb roller to ensure proper adhesive transfer.
- Sheet goods: Roll from the center towards the perimeter to allow expelling of trapped air.
- Check flooring after 2 hours and roll again if necessary.
- ** Wait 6 hours before heat welding on sheet goods**
- ** Wait 48 hours before wet mopping, stripping, or finishing the floor**

NOTE: Foot traffic may be allowed immediately when installing into dry adhesive. For installations into wet or semi-wet adhesive, allow 12 hours before traffic.

PRECAUTIONARY NOTE: THIS PRODUCT DOES NOT FORM A MOISTURE VAPOR BARRIER AND WILL NOT PROTECT FLOOR COVERING FROM HIGH MOISTURE AND pH