

Suitable Substrates

Use on concrete substrates with up to 90% RH for flooring installed on, above, or below grade (per ASTM F2170), and pH up to 9.

Cleanup

While wet, always apply soapy water to a clean cloth and wipe away adhesive. When material is dry, use denatured alcohol or appropriate adhesive remover. Do not pour directly onto flooring. Always check for compatibility on a piece of scrap flooring.

Storage

Store unopened between 50-90°F. Shelf life is 2 years unopened. Do not allow product to freeze.

Disclaimer

Users should determine the suitability of this information and product for their own purpose or application. The manufacturer is not responsible for the misuse of this product. This adhesive is only warranted to maintain an adhesive bond when used as prescribed in this document. ASTM 2659 impedance readings that exceed 3% may void the warranty.

Not a dangerous substance or mixture according to OSHA 29 CFR 1910. 1200.

First Aid Measures

Eye contact: Rinse immediately with plenty of water also under the eyelids, for at least 15 minutes. Do not rub affected areas. If eye irritation persists: Get medical advice/attention.

Skin contact: Wash off immediately with plenty of water for at least 15 minutes. In the case of skin irritation or allergic reactions see a physician. Inhalation: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

Ingestion: Do not induce vomiting without medical advice. Never give anything by mouth to an unconscious person. If symptoms persist, call a physician. Self-protection of the first aider: Use personal protective equipment as required.

Disposal

Dispose of in accordance with local, regional, national, and international regulations as specified. Read SDS for detailed product information. SDS may be obtained by visiting the website.

24-HOUR EMERGENCY CONTACT Chemtrec (Transport/Environmental)

1-800-424-9300 or 1-703-527-3887 (Outside U.S.)

Rocky Mountain Poison Center: 1-866-767-5089



PH-3

PREMIUM MULTI-PURPOSE ADHESIVE

APPLICATIONS & COVERAGE

Broadloom/ActionBac

Up to 10 sqy/gallon


1/8" x 1/8" x 1/16" V



Felt Back Sheet

Up to 180 sqft/gallon

1/16" x 1/16" x 1/16" Square



Smooth-Backed Carpet

Up to 180 sqft/gallon

3/32" x 3/32" x 3/32" V



Rough-Back and double
bond pad to substrate

Up to 8 sqy/gallon

1/8" x 1/8" x 1/16" U



FOR PROFESSIONAL USE ONLY.
NOT LABELED FOR CONSUMER USE.
KEEP OUT OF REACH OF CHILDREN.

4 US Gallons (15.14 L)



pH
7-9



RH
Up to 90%



Foot Traffic
As Soon As 12 Hrs

Instructions & Additional Info

For detailed installation guidelines, approved substrates, proper substrate preparation, technical data sheet, and safety data sheet, please see website.

APPROVED PRODUCTS:

ActionBac, Enhancer Back, Woven Back, Axminster, Double Bond/Double Glue Down Carpet and pad installations, Needle-punched, Latex Unitary Backed, Urethane Backed, Felt-Backed Sheet

INSTALLATIONS:

DISCLAIMER: FOLLOW THESE INSTRUCTIONS COMPLETELY OR DO NOT USE THIS PRODUCT.

- *** If unfamiliar with a product, always perform a bond test. Spread a small area of adhesive and install the desired floor covering into the adhesive to ensure the desired bond is achieved. ***
- After surface preparation, spread adhesive using the determined trowel as needed for desired floor covering type.
- Follow flooring manufacturer's guidelines for layout, design and any special precautions for installation.

POROUS SUBSTRATE

- After spreading the adhesive using the determined trowel, allow 10-25 minutes for adhesive to flash off (installing into the adhesive with a 100% transfer to floor covering backing).
- Working time: Will vary depending on ambient conditions and porosity of the substrate.
- Be sure to install floor covering during the working time of the adhesive or loss of adhesion could occur.

NON-POROUS SUBSTRATE

- After spreading the adhesive using the determined trowel, wait until the adhesive becomes tacky and develops legs installing into the adhesive with 100% transfer to floor covering backing.
- Working time: Will vary depending on ambient conditions and porosity of the substrate.
- Be sure to install floor covering during the working time of the adhesive or loss of adhesion could occur.
- After installation, roll flooring with 75-100lb roller to ensure proper adhesive transfer. Roll from the center towards the perimeter to allow expelling of trapped air.

NOTE: Foot traffic is typically allowed in up to 12 hours, heavy loads after 48 hours and five days for regular maintenance.

It is up to the end user to determine the proper application and coverage rate.

Suitable Substrates

Use on concrete substrates with up to 90% RH for flooring installed on, above, or below grade (per ASTM F2170), and pH up to 9.

Cleanup

While wet, always apply soapy water to a clean cloth and wipe away adhesive. When material is dry, use denatured alcohol or appropriate adhesive remover. Do not pour directly onto flooring. Always check for compatibility on a piece of scrap flooring.

Storage

Store unopened between 50-90°F. Shelf life is 2 years unopened. Do not allow product to freeze.

Disclaimer

Users should determine the suitability of this information and product for their own purpose or application. The manufacturer is not responsible for the misuse of this product. This adhesive is only warranted to maintain an adhesive bond when used as prescribed in this document. ASTM 2659 impedance readings that exceed 3% may void the warranty.

Not a dangerous substance or mixture according to OSHA 29 CFR 1910. 1200.

First Aid Measures

Eye contact: Rinse immediately with plenty of water also under the eyelids, for at least 15 minutes. Do not rub affected areas. If eye irritation persists: Get medical advice/attention.

Skin contact: Wash off immediately with plenty of water for at least 15 minutes. In the case of skin irritation or allergic reactions see a physician. Inhalation: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

Ingestion: Do not induce vomiting without medical advice. Never give anything by mouth to an unconscious person. If symptoms persist, call a physician. Self-protection of the first aider: Use personal protective equipment as required.

Disposal

Dispose of in accordance with local, regional, national, and international regulations as specified. Read SDS for detailed product information. SDS may be obtained by visiting the website.

24-HOUR EMERGENCY CONTACT Chemtrec
(Transport/Environmental)
1-800-424-9300 or 1-703-527-3887 (Outside U.S.)
Rocky Mountain Poison Center: 1-866-767-5089



PH-3

PREMIUM MULTI-PURPOSE ADHESIVE

APPLICATIONS & COVERAGE

Broadloom/ActionBac

Up to 10 sqy/gallon

1/8" x 1/8" x 1/16" V

1/8" x 1/8" x 1/16"

Felt Back Sheet

Up to 180 sqft/gallon

1/16" x 1/16" x 1/16" Square

1/16" x 1/16" x 1/16" SQ

Smooth-Backed Carpet

Up to 180 sqft/gallon

3/32" x 3/32" x 3/32" V

3/32" x 3/32" x 3/32"

Rough-Back and double bond pad to substrate

Up to 8 sqy/gallon

1/8" x 1/8" x 1/16" U

1/8" x 1/8" x 1/16"

FOR PROFESSIONAL USE ONLY. NOT LABELED FOR CONSUMER USE.
KEEP OUT OF REACH OF CHILDREN.

1 US Gallon (3.79 L)



Foot Traffic
As Soon as 12 hrs



Foot Traffic
As Soon as 12 hrs

Instructions & Additional Info

For detailed installation guidelines, approved substrates, proper substrate preparation, technical data sheet, and safety data sheet, please see website.

APPROVED PRODUCTS:

ActionBac, Enhancer Back, Woven Back, Axminster, Double Bond/ Double Glue Down Carpet and pad installations, Needle-punched, Latex Unitary Backed, Urethane Backed, Felt-Backed Sheet

INSTALLATIONS:

DISCLAIMER: FOLLOW THESE INSTRUCTIONS COMPLETELY OR DO NOT USE THIS PRODUCT.

1. *** If unfamiliar with a product, always perform a bond test. Spread a small area of adhesive and install the desired floor covering into the adhesive to ensure the desired bond is achieved. ***
2. After surface preparation, spread adhesive using the determined trowel as needed for desired floor covering type.
3. Follow flooring manufacturer's guidelines for layout, design and any special precautions for installation.

POROUS SUBSTRATE

- After spreading the adhesive using the determined trowel, allow 10-25 minutes for adhesive to flash off (installing into the adhesive with a 100% transfer to floor covering backing).
- Working time: Will vary depending on ambient conditions and porosity of the substrate.
- Be sure to install floor covering during the working time of the adhesive or loss of adhesion could occur.

NON-POROUS SUBSTRATE

- After spreading the adhesive using the determined trowel, wait until the adhesive becomes tacky and develops legs installing into the adhesive with 100% transfer to floor covering backing.
- Working time: Will vary depending on ambient conditions and porosity of the substrate.
- Be sure to install floor covering during the working time of the adhesive or loss of adhesion could occur.
- After installation, roll flooring with 75-100lb roller to ensure proper adhesive transfer. Roll from the center towards the perimeter to allow expelling of trapped air.

NOTE: Foot traffic is typically allowed in up to 12 hours, heavy loads after 48 hours and five days for regular maintenance.

It is up to the end user to determine the proper application and coverage rate.