

STEALTH

SONIC ISOLATION UNDERLAYMENT



APPLICATION

- RESIDENTIAL
- COMMERCIAL

APPROVED FOR USE UNDER

- LVT/LVP
- LAMINATE
- ENGINEERED WOOD
- HARDWOOD

DIMENSIONS AND PACKAGING

- ROLL SIZE 200/SF
- ROLL WIDTH 36"
- ROLL WEIGHT 10.5 LBS
- THICKNESS 2 MM
- DENSITY 16LB/FT³

APPROVED SUBSTRATES

- COMPLETELY CURED CONCRETE
- INTERIOR PLYWOOD
- CEMENT BACKER UNITS
- PROPERLY PREPARED OSB

SOUND RATINGS 6" SLAB WITH DROP CEILING

- LUXURY VINYL TILES & PLANKS
IIC 73, STC 63
- LAMINATE & WOOD PRODUCTS
IIC 70, STC 71

SOUND RATINGS 6" SLAB NO CEILING ASSEMBLY

- LUXURY VINYL TILES & PLANKS
IIC 57, STC 51
- LAMINATE & WOOD PRODUCTS
IIC 54, STC 50

SOUND RATINGS 6" SLAB NO CEILING ASSEMBLY

- DELTA IIC 27 DB



MADE IN CANADA
WITH NORTH AMERICAN RAW MATERIALS





STEALTH

SONIC ISOLATION UNDERLAYMENT

FLOORING PRODUCTS: Luxury vinyl tiles and planks, laminate, engineered wood and hardwood

INSTALLATION INSTRUCTIONS

Floor Prep

Sub-floor must be level, clean and dry with no protruding nails or staples. Concrete sub-floor moisture emission rate may not exceed 3 lbs. / 1,000 sq. ft. / 24 hrs in accordance with ASTM F1869. If moisture emissions exceed this level an additional moisture barrier may be required.

ACCLIMATE UNDERLAYMENT FOR A MINIMUM OF 24 HRS. PRIOR TO INSTALLATION.

Floating Installation

1. Roll out underlayment fabric side up and parallel to the wall, in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor, leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping, and close the seams using a 2" wide aggressive adhesive tape.
4. Install the floor covering according to the manufacturer's guidelines.

Nail-Down Installation

1. Roll out underlayment fabric side up and parallel to the wall in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping and close the seams using a 2" wide aggressive adhesive tape.
4. Install the floor covering according to the manufacturer's guidelines.

BE SURE TO ADJUST THE AIR PRESSURE WHEN USING A NAIL GUN SO THAT THE NAIL/STAPLE IS FIRMLY SET BUT NOT FULLY COMPRESSING THE UNDERLAYMENT.