

# FLAMMABLE OUTDOOR CARPET ANDRESIVE

Pegamento al aire libre inflamable de la alfombra



# DESCRIPTION:

POWERHOLD 700 is a waterproof adhesive made specifically for the permanent outdoor installation of artificial grass and other outdoor carpets. This product sets rapidly and can be applied over a wide range of temperatures,  $40^{\circ}$  F to  $100^{\circ}$  F. Rain immediately after installation may slow set up time, but will not otherwise affect bond.

#### FOR INSTALLATION OF:

Use POWERHOLD 700 for carpets with the following backings: Marine-back (over porous surfaces), latex-back, poly-back, needle-punched, dry-back.

Not recommended for urethane or vinyl-backed product. Not recommended for installing non-porous products to non-porous surfaces, as the solvents cannot escape, therefore the adhesive cannot set. When installing nearly non-porous unitary backed goods to non-porous surfaces, let the adhesive tack up until it will make two inch legs when finger tested.

### **USE WITH:**

May be applied over fully-cured cement, seasoned hot-applied asphalt, metal, terrazzo, exterior grade wood decks, and APA registered underlayment grade plywood. Do not use over pressure treated lumber or plywood, adhesion problems may occur.

# PRIOR TO INSTALLATION:

Floor must be clean, level and dry. Remove all foreign substances such as wax, grease, dirt and any substance or chemical that would interfere with a good bond. Fill all holes and cracks with a cement based patching compound. Sand high spots, install felt or hardboard underlayment over tongue and groove flooring to eliminate the possibility of telegraphing.

## **INSTALLATION INSTRUCTIONS:**

1. Apply POWERHOLD 700 to clean surface with a notched trowel or spreader notched deeply enough that the beads of adhesive will reach the recessed areas of the backing. A 3/32"x3/32" v-notch trowel is considered minimum for smooth backs and 1/8" or

even 5/32" for rough-back goods.

- 2. The adhesive has an open time of up to 30 minutes depending on temperature and humidity conditions.
- 3. Allowing the adhesive to set "tacky" before laying the carpet may help prevent bubbling and speed drying.
- 4. Lay carpet into adhesive. Smooth down the carpet with firm pressure to insure good adhesive transfer to the carpet backing.
- 5. NOTE: Seams may peak slightly and bubbles may develop on some carpet within minutes after installation. This results from temporary swelling of the rubber backing, and will re-bond easily if pressed down after the adhesive sets.
- 6. Complete the installation by rolling the carpet with a light weight roller or carpet core to make certain the adhesive makes deep contact into the carpet backing.

Clean Up: Use POWERHOLD Cleaning Solvent.

#### DANGER:

FLAMMABLE! TOXIC! Vapors may ignite explosively. Prevent build-up of vapors. Open all windows and doors. Use only with cross ventilation. Keep away from heat, sparks and open flame. Do not smoke. Extinguish all flames and pilot lights, and turn off grills, stoves, heaters, electric motors, and other sources of ignition during use and until all vapors are gone. Close container after fuse. DO NOT take internally. Harmful or fatal if swallowed. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN. Avoid breathing vapors. Avoid prolonged or repeated contact with skin or contact with eyes. Contains Petroleum Distillates. Flash point of this adhesive is over 20° F. (T.O.C.)





#### **TECHNICAL SPECIFICATIONS**

# PACKAGING

4 Gallon (15.14L) Black Pails; 4 - 1 Gallon (3.785L) Pails and 12 - 1 Quart (0.95L) Containers

#### SHELF LIFE

1 - Year when stored in original, unopened container

# COVERAGE (APPROXIMATE)



Up to 110 sq. ft./gal. Up to 2.7 sq. meters/liter 3.2 mm x 3.2 mm x 1.6 mm

 Marine-back (over porous surfaces), latex-back, poly-back, needle-punched, dry-back.



Up to 160 sq. ft./gal. Up to 4.0 sq. meters/liter 2.4mm x 2.4mm x 2.4mm

 Marine-back (over porous surfaces), latex-back, poly-back, needle-punched, dry-back.